


SEH Baseline 650 Print Server: Manual Installation



KONICA MINOLTA

Introduction

The SEH Baseline 650 Print Server converts the parallel port of the magicolor 2300W, PagePro 1300W, and PagePro 1350W to a 10BaseT/100BaseTX Ethernet port, so you can connect the printer to a network.

This document explains how to download and install the printer driver and SEH 650 Baseline Print Server utilities from the web.

Note:

If you are installing the printer driver and SEH Baseline 650 Print Server utilities from one of the following CD-ROMs, use the instructions in the “SEH Baseline 650 Print Server Installation and Use” document that comes with the Print Server:

- KONICA MINOLTA *SEH 650 Baseline Print Server for the magicolor 2300W and PagePro 1300W* CD-ROM (4780221-901 or later)
- KONICA MINOLTA *SEH 650 Baseline Print Server for the magicolor 2300W and PagePro 1350W* CD-ROM (4780222-901 or later)

Requirements

- magicolor 2300W, PagePro 1300W, or PagePro 1350W
- SEH 650 Baseline Print Server

Installation

- 1 Turn off and unplug the printer and then disconnect the interface cable(s).
- 2 Attach the Baseline 650 Print Server to the printer’s parallel port.
- 3 Connect the Ethernet network cable to the Baseline 650 Print Server.
- 4 Plug in the Baseline 650 Print Server, and then plug in the printer.

Note:

Do not turn on the printer yet.

- 5 Create an SEH650 folder on your computer.
-

-
- 6 Download the SEH650.EXE file to the SEH650 folder.

Note:

Do not do anything with this file yet. You must first install the printer driver in the next step.

- 7 If you already have a printer driver for your printer installed on your computer, uninstall it by going to Windows Start>Programs>Konica Minolta *printername* Utilities and choosing KONICA MINOLTA *printername* Uninstall.

Note:

In order for the SEH printer driver in the next step to install correctly, you must first uninstall the existing printer driver.

- 8 Download and install the appropriate SEH printer driver from the KONICA MINOLTA PRINTING SOLUTIONS U.S.A., INC. web site:

- PagePro 1300W: Go to printer.konicaminolta.com/support/current_printers/pp1300w_sup.htm#seh
- PagePro 1350W: Go to printer.konicaminolta.com/support/current_printers/pp1350w_sup.htm#seh
- magicolor 2300W: Go to printer.konicaminolta.com/support/current_printers/mc2300w_sup.htm#seh

Notes:

- The appropriate printer driver is identified on the drivers web page as “Windows xx SEH Printer Driver” (where xx is your Windows operating system).
- You must install this version of the printer driver EVEN IF you already have a printer driver installed. This version contains support for the SEH Baseline 650 Print Server.
- After you download the printer driver file, double-click on the xxxx.exe filename to uncompress the file. Then double-click on setup.exe to install the printer driver.
- During printer driver installation, select all of the default options: “Local Printer,” “LPT1,” and the default printer name.

- 9 Once the printer driver installation is complete, choose OK.
- 10 In the SEH650 folder on your computer, double-click the SEH650.EXE file to uncompress the files to the same folder.
- 11 In the SEH650\PRINTMON folder, double-click Setup.exe to set up the SEH Print Monitor.
-

-
- 12 When the installation is complete, choose Finish.
 - 13 In the SEH650\WIZARD\WINxx folder (where xx is your Windows operating system), double-click Printerwizard.exe to start the SEH Printer Wizard.

Notes:

- The Printer Wizard performs the software connection between the SEH Baseline 650 Print Server and the printer.
- On the Welcome screen, when prompted to verify all connections, turn on the printer.
- On the “Print server list or IP address” screen, select the method by which you will locate the print server.

If your network is running DHCP

- 1 Choose “Select a print server from a list” and then choose Next.
- 2 In the Select a Print Server screen, select the SEH Baseline Print Server. (You can identify it because its “Type” is “Baseline” and its “Printer” is the printer you installed earlier and then choose Next.

If your network isn't running DHCP

- 1 Choose “Select a print server using its IP address” and then choose Next.
 - 2 Type the IP address or host name of the Baseline Print Server and then choose Next.
- When prompted to select a printer driver, select the one you installed in step 8.
Note: DO NOT choose the Install New Driver button.
 - When prompted for a printer name, accept the default printer name.

- 14 When the installation is complete, choose Finish.
 - 15 Go to Windows Start>Settings>Printers [and Faxes].
 - 16 You will find two drivers installed for your printer:
 - Konica Minolta *printername*: Delete this driver.
 - Konica Minolta *printername* (Copy 1): Rename this driver by removing “(Copy 1)” from the name.
 - 17 Restart the Status Display by going to Windows Start>Programs>Konica Minolta *printername* Utilities and choosing Konica Minolta *printername* Status.
After a few seconds, Status Display finds the newly installed printer.
 - 18 The installation is complete. You can now use your printer on the network.
-

Use

The Baseline 650 Print Server has its own home page. To open it, open your browser (Internet Explorer 4 or later, or Netscape 3 or later) and then type the Print Server's IP address in the address bar.

For more information, refer to the *BaseLine Print Servers User Manual* in PDF format in the SEH650 directory on your computer.